

U ***SER MANUAL***

C-Weigh Forks

WiFi Connectivity

Manual Number 6934275


cascade[®]
corporation

Cascade is a Registered Trademark of Cascade Corporation

Configuring the WLAN connection with the XpicoWiFi

Cascade Weigh Forks equipped with WiFi data transfer use a dual layer WiFi system. The Xpico WiFi chip has an Access Point port (ap0) that runs an embedded web style “SoftAP” that is always available to configure the WLAN (wlan0) to connect to the facility wireless network. The following steps will walk through initial connection to a facility network. Connection to networks requiring a single passkey are supported. The system does not support networks requiring a user acceptance of terms of service.

Step 1: On your computer, open the WLAN connection manager.




Step 2: Connect to the XpicoWiFi_XXXXXX (last six digits depend on the address of the Xpico installed). By default the SoftAP mode is enabled with a default SSID of XpicoWiFi_XXXXXX. Where XXXXXX are the last six characters of the unique Xpico Wi-Fi serial number. This number is available on the module label inside the indicator. For example if the serial number on label were 0080A398010E then the SSID would be XpicoWiFi_98010E. Each indicator has a unique WiFi address.




SERIAL NUMBER

Step 3: The default security for Xpico Wi-Fi SoftAP is WPA2 and the network security key is “**XPICOWIFI**”.



Step 4: Open a standard browser (E.g. Internet Explorer®, Firefox®, Chrome™, Safari® etc.) and in the address field of the browser enter the following IP Address: 192.168.0.1. Alternatively you can use the web site address: xpicowifi.lantronix.com.



When prompted enter the username, “**admin**”, and password, “**PASSWORD**”, to access the embedded SoftAP Configuration and Management Web pages.



Step 5: The initial page encountered is the “Status” page. The two areas of interest are the interface ap0 info and the interface wlan0 info. The wlan0 is configured to connect to your network. The ap0 is the current access point used to configure the wlan0.

The screenshot shows the 'Status' page of the xPico Wi-Fi interface. The left sidebar contains a menu with options: QuickConnect, Status (selected), AES Credentials, CPM, Clock, Device, Diagnostics, Discovery, File System, HTTP, Line, Modem Emulation, Monitor, NTP, Network, Power, SPI, Tunnel, Users, and WLAN Profiles. The main content area is divided into two sections: Product Information and Network Settings.

| Product Information | | |
|---------------------|-----------------------|--|
| Product Type: | xPicoWiFi | |
| Firmware Version: | 1.3.0.1R4 | |
| Build Date: | Dec 5 2014 (17:17:11) | |
| Serial Number: | 0080A3AE1142 | |
| Uptime: | 0 days 00:10:03 | |
| Permanent Config: | saved | |

| Network Settings | | |
|-------------------|-------------------------------------|--------------|
| MAC Address: | 00:80:A3:AE:11:42 | |
| Interface ap0 | | |
| State: | Up | |
| SSID: | XpicoWiFi_AE1142 | |
| Security Suite: | WPA2 | |
| IP Address: | 192.168.0.1/24 | |
| Interface wlan0 | | |
| Connection State: | Disconnected | |
| Line Settings | | |
| Line 1: | 9600, None, 8, 1, None Tunnel | |
| Line 2: | 9600, None, 8, 1, None Command Line | |
| Tunneling | | |
| | Accept Mode | Connect Mode |
| Tunnel 1: | Waiting | Disabled |
| Tunnel 2: | Inhibited | Inhibited |

The side bar allows modification and access to features of the xPico chipset. Of particular interest are the “QuickConnect”, “Network” and “WLAN Profiles” pages.

The “QuickConnect” page offers the ability to identify available access points and configure the wlan0 client interface on Xpico WiFi to establish connection. QuickConnect learns most of the connection properties from the selected access point and prompts the user only for the security parameters. The settings are then saved under a corresponding new or existing profile on the “WLAN Profiles” page for future operation of the WLAN Client interface. Modification of the active WLAN Profile is accomplished using the “Network” page.

Step 6 QuickConnect:

Click “QuickConnect” to access the page. Click “Scan” to bring up the available networks.

The screenshot shows the 'WLAN Link Scan' page in the Web Manager. The left sidebar is the same as in the previous screenshot. The main content area has a title 'WLAN Link Scan' and a search bar with a 'Scan' button. Below the search bar is a table listing detected networks.

| Network Name | BSSID | Ch | RSSI | Security Suite |
|-----------------------|-------------------|----|---------|----------------|
| NETGEAR35 | 10:DA:43:D1:D3:0B | 7 | -48 dBm | WPA2-CCMP |
| CascadeGuest | 18:8B:9D:13:AF:31 | 6 | -67 dBm | WPA2-CCMP |
| CascadePrtShopFloor01 | 18:8B:9D:13:AF:33 | 6 | -67 dBm | WPA2-CCMP |
| CascadeWPA2 | 18:8B:9D:13:AF:30 | 6 | -68 dBm | WPA2-CCMP |
| CascadeThinClient | 18:8B:9D:13:AF:34 | 6 | -68 dBm | WPA2-CCMP |
| CascadeMobile | 18:8B:9D:13:AF:32 | 6 | -68 dBm | WPA2-CCMP |
| CascadeMisc | 18:8B:9D:13:AF:35 | 6 | -69 dBm | WPA2-CCMP |
| CascadeWPA2 | 58:97:BD:F9:EC:20 | 1 | -83 dBm | WPA2-CCMP |

On the right side of the page, there is a note: "This page shows a scan of the wireless devices within range of the device. Up to 20 networks sorted by RSSI are shown. It reports: Network name (Service Set Identifier), Basic Service Set Identifier, Channel number, Received Signal Strength Indication and Security Suite. Click on any network name for QuickConnect configuration."

The xPico Wi-Fi scans and displays up to 20 wireless devices in order of strongest signal strength. Click on the network of your desired Access Point. When the selected Access Point profile displays, enter the password and click Submit to directly connect to the Access Point and to add the profile and configuration details to the “WLAN profiles” page.

The screenshot shows the 'xPico Wi-Fi' interface with the 'WLAN Profile "NETGEAR35"' configuration page. The left sidebar contains a menu with options like QuickConnect, Status, AES Credentials, CPM, Clock, Device, Diagnostics, Discovery, File System, HTTP, Line, Modem Emulation, Monitor, NTP, Network, Power, SPI, Tunnel, Users, and WLAN Profiles. The main content area is divided into sections: 'Connect To' (Network Name (SSID): NETGEAR35, BSSID: 10:DA:43:D1:D3:0B, Security Suite: WPA2-CCMP, Signal Strength: -42 dBm), 'Security' (Key Type: Passphrase selected, Password: masked), and 'Advanced'. There are 'Apply' and 'Submit' buttons at the bottom. A right-hand text box provides instructions on using the 'Apply' and 'Submit' buttons and mentions that settings pertain to a WLAN Profile on the device.

Once added, the Quick Connect profile is accessible and configurable through WLAN Profiles. Clicking on WLAN profiles displays a list of stored profiles. The yellow WiFi icon indicates the active network. If the icon is not present, none of the WLAN Profiles are connected.

The screenshot shows the 'xPico Wi-Fi' interface with the 'WLAN Profile Management' page. The left sidebar is the same as the previous screenshot, with 'WLAN Profiles' highlighted. The main content area has a 'WLAN Profile Management' header and a table with columns 'View or Edit' and 'Delete'. The table lists two profiles: 'CascadeThinClient' and 'NETGEAR35' (which has a yellow WiFi icon). Below the table is a 'Create new WLAN Profile' button. A right-hand text box provides instructions on how to view, edit, delete, or create profiles, and explains the meaning of the WiFi icon.

Clicking on the profile we will bring up its status. Here you can enable or disable the connection, and change either the password and or encryption type.

xPico® Wi-Fi® LANTRONIX®

QuickConnect
Status
AES Credentials
CPM
Clock
Device
Diagnostics
Discovery
File System
HTTP
Line
Modem Emulation
Monitor
NTP
Network
Power
SPI
Tunnel
Users
WLAN Profiles

WLAN Profile NETGEAR35 Configuration

These settings pertain to a WLAN Profile on the device.

Use the **Apply** button to try out settings on the WLAN without saving them to Flash. If the settings do not work, when you reboot the device, it will still have the original settings.

Use the **Submit** button to both update the WLAN settings and save them to Flash.

If the device is connecting to an access point on a different wireless channel, current connection to the soft AP interface of the device may be dropped due to the switch of channel. Reconnect to the soft AP interface in order to continue access to the device.

| Basic | |
|-------------------|---|
| Network Name: | NETGEAR35 |
| State: | <input checked="" type="radio"/> Enabled <input type="radio"/> Disabled |
| Security | |
| Suite: | WPA2 |
| WPAx Key Type: | Passphrase |
| WPAx Passphrase: | •••••••• |
| WPAx Encryption: | <input checked="" type="checkbox"/> CCMP <input type="checkbox"/> TKIP |
| Advanced | |
| TX Power Maximum: | 17 dBm |
| Power Management: | <input type="radio"/> Enabled <input checked="" type="radio"/> Disabled |

Copyright © Lantronix, Inc. 2007-2014. All rights reserved.

Step 6: Clicking Network in the side bar allows access to the network configuration page. Here you can modify the SSID, Security Suite Type and Security passphrase for the ap0 and wlan0. Modification to any of these parameters requires a reset/power cycle of the module in order to take effect.

xPico® Wi-Fi® LANTRONIX®

QuickConnect
Status
AES Credentials
CPM
Clock
Device
Diagnostics
Discovery
File System
HTTP
Line
Modem Emulation
Monitor
NTP
Network
Power
SPI
Tunnel
Users
WLAN Profiles

ap0 wlan0

Interface Link

Status Configuration

Interface ap0 Status

This page is used to view the status of the Network interface on the device.

There are two columns displayed. The first column shows the current operational settings. The second column shows the expected settings after the device is rebooted.

When DHCP fails to discover an IP Address, a new address will automatically be generated using AutoIP. This address will be within the 169.254.x.x space. Access Point will always use static IP assigned.

| Property | Status | |
|--------------|-------------------|--------------|
| Status: | Link up | |
| MAC Address: | 00:80:A3:AE:11:42 | |
| | Current | After Reboot |
| State: | Enabled | Enabled |
| IP Address: | 192.168.0.1/24 | (DHCP) |

Copyright © Lantronix, Inc. 2007-2014. All rights reserved.

Caution: It is **strongly suggested** not to make any changes to the ap0 settings as if the new passphrase is lost the chipset will need to be manually reset.

Clicking on wlan0 will show the status of the current network connection.

The screenshot shows the 'xPico Wi-Fi' web interface. On the left is a sidebar menu with options like QuickConnect, Status, AES Credentials, CPM, Clock, Device, Diagnostics, Discovery, File System, HTTP, Line, Modem Emulation, Monitor, NTP, Network (highlighted), Power, SPI, Tunnel, Users, and WLAN Profiles. The main content area is titled 'Interface wlan0 Status'. It includes tabs for 'Interface' and 'Link', and sub-tabs for 'Status' and 'Configuration'. The 'Status' sub-tab is active, displaying a table of network properties. A 'Renew' button is visible next to the IP address. On the right, a text box explains the page's purpose and provides details about DHCP and static IP assignment.

| Property | Status | |
|------------------|-------------------|--------------|
| Status: | Link up | |
| | [Renew] | |
| MAC Address: | 00:80:A3:AE:11:42 | |
| | Current | After Reboot |
| State: | Enabled | Enabled |
| DHCP Client: | Enabled | Enabled |
| IP Address: | 192.168.1.3/24 | (DHCP) |
| Default Gateway: | 192.168.1.1 | (DHCP) |
| Hostname: | | |
| Primary DNS: | 192.168.1.1 | (DHCP) |
| Secondary DNS: | 0.0.0.0 | (DHCP) |

The IP Address listed is the address of the indicator. In this case 192.168.1.3. Requests for the weight are sent to port 10001.

Clicking Configuration will allow you to change to static IP and make changes to the addressing as needed.

This screenshot shows the 'xPico Wi-Fi' web interface with the 'Interface wlan0 Configuration' page. The sidebar menu is the same as in the previous screenshot. The main content area has the 'Configuration' sub-tab active. It contains a form for configuring the network interface. On the right, a text box explains that these settings pertain to the Network Interface and that changes will take effect after a reboot or wake from sleep.


| | |
|------------------|---|
| State: | <input checked="" type="radio"/> Enabled <input type="radio"/> Disabled |
| DHCP Client: | <input checked="" type="radio"/> Enabled <input type="radio"/> Disabled |
| IP Address: | 192.168.2.147/24 |
| Default Gateway: | 192.168.1.1 |
| Hostname: | |
| Primary DNS: | 192.168.2.3 |
| Secondary DNS: | 0.0.0.0 |

Step 7: Test your connection.


From a computer connected to the same network launch a command line interface. Type “command prompt” in the search bar to launch command line session.



Type ping and the IP address. In this case “ping 192.168.1.3” to verify connection to the indicator through your network. A successful connection will result in a listing of connection reply’s and Ping statistics.




Launch a telnet session by typing telnet.



If the telnet command is not recognized, use the following steps to enable telnet.


How to Install Telnet in Windows 10

1. Open “Control Panel”.
2. Open “Programs”.
3. Select the “Turn **Windows** features on or off ” option.
4. Check the “**Telnet Client**” box.
5. Click “OK”. A box will appear that says “**Windows** features” and “Searching for required files”.When complete, the **Telnet** client should be installed in **Windows**.




[Windows 10: Install Telnet Client - Technipages](https://www.technipages.com/windows-10-enable-telnet)
<https://www.technipages.com/windows-10-enable-telnet>

To open a telnet connection to the indicator type “o” for open, followed by the ip address of the indicator, and then the port 10001.




```
Command Prompt - telnet
Welcome to Microsoft Telnet Client
Escape Character is 'CTRL+]'
Microsoft Telnet> o 192.168.1.3 10001
```

Press enter and the telnet session will have started.



```
Telnet 192.168.1.3
Welcome to Microsoft Telnet Client
Escape Character is 'CTRL+]'
Microsoft Telnet> o 192.168.1.3 10001
Connecting To 192.168.1.3...
```

Type a “p” to request the weight. The response will be in the form of weight, units and GR or NT.




```
Telnet 192.168.1.3
1825 lb GR
p 1825 lb GR
p
p 2535 lb GR
```

Alternatively Use the “WiFi Communication Demo Utility” available from Cascade.

Install the Utility by copying it to your desktop.



Launch the Demo Utility and enter the indicator IP Address. Click “Get Weight”.



The base code for the utility is available to assist in creating custom code.

Technical data Xpico

> Wireless LAN Interface

- IEEE 802.11 b/g and IEEE 802.11n (single stream) WLAN interface (2.4 GHz only)
- IEEE 802.11 d/h/i/j/k/w/r
- u.FL connector for external antenna

> Host Interface

- Dual Serial Port, SPI, USB 2.0* (device)
- 8 GPIO

> Networking Capabilities

- Soft Access Point with DHCP Server
- Lantronix SmartRoam™ Technology* continually tracks Wi-Fi signal strength within range, along with pre-authentication and caching resulting in smooth and automatic transition to access points without delay.
- QuickConnect: Dynamic Profiles facilitate easy and rapid connections to access points

> Architecture

- ARM Cortex M3 class processor with on-chip Flash and SRAM
- 1MB Flash and 128 KB SRAM
- 1MB SPI Flash storage

> Power

- Input Voltage: 3.3VDC
- Low power consumption of approximately 6µA standby

> Serial Interface

- Two Serial CMOS Ports (3.3V, 5V tolerant)
- 300 to 921.6 Kbps
- Flow control XON/XOFF, RTS/CTS (SPort 1 only)
- Lantronix tunneling application

> Network Protocols

- TCP/IP, UDP/IP, DHCP, ARP, ICMP, DHCP, Auto-IP, DNS, SNMPv1

> Management and Control

- Web Server - Landing Page
- CLI (Serial Monitor Port)
- XML import and Export (XCR)
- Field upgradable firmware (OTA)

> Security

- IEEE 802.11i Support – WPA-Personal, WPA2-Personal
- 256-bit AES Encryption*

> Physical Interface

- 40-pin Board-to-Board SMT Connector

> Environmental

- Operating Temperature: -40° to +85° C
 - For operation over +70° C a thermal pad is required
- Storage Temperature : -40° to +85° C
- Relative Humidity: 0% to 90% non-condensing

- ◆ **Certifications:** FCC, IC, EU, Japan, UL, CE, AU/NZ

Addresses and Port Numbers

Hardware Address

The hardware address is also referred to as the physical address or MAC address, and can be found on the product label of the device. Sample hardware address:

- ◆ 00-80-A3-FF-FF-FF
- ◆ 00:80:A3:FF:FF:FF

IP Address

Every device connected to an IP network must have a unique IPv4 address. This address references the specific unit.

Port Numbers

Available IP address port numbers enabled and accessible on the xPico Wi-Fi unit include the following:


- ◆ TCP Port 80: HTTP Server (Web Manager configuration)
- ◆ TCP Port 10001: Tunnel (Line 1)
- ◆ TCP Port 10002: Tunnel (Line 2)

Product Information Label

The product information label on the unit contains the following information about the specific unit:

- ◆ Lantronix Datamatrix Code
- ◆ Product Revision
- ◆ Part Number
- ◆ Serial Number Hardware Address (MAC Address)
- ◆ Manufacturing Date Code

Figure 2-1 xPico Wi-Fi Product Label



Configuration methods

For the unit to operate correctly on a network, it must have a unique IP address on the network. There are three basic methods for logging into the device server to assign an IP address and configure the unit:

- * DeviceInstaller: Assign an IP address and view the current Xpico configuration using a Graphical User Interface (GUI) on a PC attached to a network. (See 3 Using DeviceInstaller.)
- * Web-Manager: Through a web interface, configure the Xpico and its settings using the Xpico's Web-Manager. (See 4 Configuration Using Web Manager)
- * Serial & Telnet Ports: There are two approaches to accessing Serial Mode. Make a Telnetconnection to the network port (9999) or connect a terminal (or a PC running a terminal emulation program) to the unit's serial port. (See 5 Configuration via Telnet or Serial Port (Setup Mode))

Reference Documentation

For more information on the use and operation of the Xpico Wi-Fi Device Server please refer to the latest product documents which are available on the Product Website.

www.lantronix.com/support/documentation.

Do you have questions you need answered right now?

Call your nearest Cascade Service Department.

Visit us online at www.cascorp.com

AMERICAS**Cascade Corporation
U.S. Headquarters**

2201 NE 201st
Fairview, OR 97024-9718
Tel: 800-CASCADE (227-2233)
Fax: 888-329-8207

Cascade Canada Inc.

5570 Timberlea Blvd.
Mississauga, Ontario
Canada L4W-4M6
Tel: 905-629-7777
Fax: 905-629-7785

Cascade do Brasil

Praça Salvador Rosa,
131/141-Jordanópolis,
São Bernardo do Campo - SP
CEP 09891-430
Tel: 55-13-2105-8800
Fax: 55-13-2105-8899

EUROPE-AFRICA**Cascade Italia S.R.L.
European Headquarters**

Via Dell'Artigianato 1
37030 Vago di Lavagno (VR)
Italy
Tel: 39-045-8989111
Fax: 39-045-8989160

Cascade (Africa) Pty. Ltd.

PO Box 625, Isando 1600
60A Steel Road
Sparton, Kempton Park
South Africa
Tel: 27-11-975-9240
Fax: 27-11-394-1147

ASIA-PACIFIC**Cascade Japan Ltd.**

2-23, 2-Chome,
Kukuchi Nishimachi
Amagasaki, Hyogo
Japan, 661-0978
Tel: 81-6-6420-9771
Fax: 81-6-6420-9777

Cascade Korea

121B 9L Namdong Ind.
Complex, 691-8 Gojan-Dong
Namdong-Ku
Inchon, Korea
Tel: +82-32-821-2051
Fax: +82-32-821-2055

Cascade-Xiamen

No. 668 Yangguang Rd.
Xinyang Industrial Zone
Haicang, Xiamen City
Fujian Province
P.R. China 361026
Tel: 86-592-651-2500
Fax: 86-592-651-2571

**Cascade India Material
Handling P Ltd**

Sy no 271/8, Ingawale Patil
Estate,
Godown No.9,10 & 11, Bhugaon,
Off Paud Road, Tal Mulshi, Dist
Pune 411 042

Cascade Australia Pty. Ltd.

1445 Ipswich Road
Rocklea, QLD 4107
Australia
Tel: 1-800-227-223
Fax: +61 7 3373-7333

Cascade New Zealand

15 Ra Ora Drive
East Tamaki, Auckland
New Zealand
Tel: +64-9-273-9136
Fax: +64-9-273-9137

**Sunstream Industries
Pte. Ltd.**

18 Tuas South Street 5
Singapore 637796
Tel: +65-6795-7555
Fax: +65-6863-1368

