



# Installation Instructions


## Single-Double Pallet Handler Mounting Conversion Kits 6130258 & 6130364

This sheet shows the installed conversion parts required when changing a Cascade F-Series Single-Double Pallet Handler from Class II to Class III (Kit 6130364) or from Class III to Class II (Kit 6130258). Refer to Installation Manual 6129013 for complete installation details to mount the attachment on the truck.




**WARNING:** Make sure that upper and lower sideshifting bearings are in place and properly installed. Adjust lower hooks for clearance and tighten to proper torque value. Refer to Installation Manual 6129013.

### CLASS III → II Conversion Kit 6130258



### CLASS II → III Conversion Kit 6130364



**NOTE:** This information should not be interpreted as the basis for warranty claims unless so designated.

**cascade**®  
corporation

#### For Technical Support . . .

Call: 1-800-227-2233 Fax: 1-888-329-8207  
Internet: [www.cascorp.com](http://www.cascorp.com)  
Write: Cascade Corporation, PO Box 20187, Portland, OR 97294

#### To Order Parts . . .

Call: 1-888-227-2233 Fax: 1-888-329-0234  
Internet: [www.cascorp.com](http://www.cascorp.com)  
Write: Cascade Corporation, 2501 Sheridan Ave., Springfield, OH 45505